



5500 Cenex Drive
Inver Grove Heights, MN 55077-1721

Creating connections to
empower agriculture

Insite 360 – Remote Software Installation Instructions

1. Log-in to Insite360
2. Click → *Remote Software Update* → *Device Version Assignment*
3. Find the location(s) you'd like to upgrade
4. Click → *Detail/Update*

On Latest Release	Update Available	Download Scheduled	Package Download In Progress	Update Scheduled	Software Update In Progress	Update Completed	Error
0	2	0	0	0	0	0	0

Store Number	OVRI d	Role	Address	City	State	Brand	Installed	Update Version	Current Status	OS Updates	Download Date	Install Date	Health Check
PX-60 & Express Lane	203236	Lab	5500 CENEX DRIVE	INVER GROVE HEIGHTS	5500 CENEX DRIVE	CENEX	20.04.32.01A	Update Available	Update Available				View Detail/Update
CENEX Lab - Passport Edge	889265	Lab	5500 CENEX DR	INVER GROVE HEIGHTS	MIN	CENEX	20.04.32.01A	Update Available	Update Available				View Detail/Update

5. Underneath “Software Update” choose the software version you'd like to upgrade to
 - a. If you'd like to upgrade immediately, Click → *Immediate Send*
 - b. If you'd like to upgrade your software on a specific date or time, specify the date/time you would like the software upgrade to take place
6. Click → *Save*. Once the software is downloaded, upgrade will take place during the next store close process

Client3PinpadSerialNumber: 260-905-541
Client3PinpadVersion: 5.0.17-20180801

Site Role:
☐ Production
☐ Field Trial
☒ Lab

Store Data
Store Number: PX-60 & Express Lane
Address: 5500 CENEX DRIVE
City: INVER GROVE HEIGHTS
State: 5500 CENEX DRIVE
Time Zone: America/Chicago

Software Update
☒ No Update
☐ Latest Overall Version: 20.04.32.01B
☐ Latest revision for the current version: 20.04.32.01B
☐ Immediate Send

Times are local at the site

Download Date: : : AM
Install Date: : : AM

[Save](#) [Cancel](#)

**Please note, website appearance may not exactly mirror the above screenshots. If you have any questions or need help with navigation, please contact Gilbarco*